## Main Features of this Decoder

- Back EMF Load Compensation for superior slow speed control even with heavy loads.
- **<u>Quiet Drive</u>** creates **SUPER QUIET** engine performance.
- <u>Autodetect</u> for realistic throttle response when using DC power.
- **Dimmed Brightness** of bulbs or LEDs is adjustable.
- Variable Momentum lets you make custom acceleration curves.
- Mars, Gyra, and Rotary Beacon are adjustable.
- <u>Decoder Lock</u> for programming same address decoders independently.
- <u>Function Remapping</u>: 13 buttons for most lights, 7 buttons for operations.
- **Other Features of This Decoder:** This decoder has too many features that could be listed on this page. For the complete list of available features, print out the "Additional Programing Guide" that can be found in the literature section of our website ( www.tcsdcc. com). Some of the features include: Function Remapping, 3 Point Acceleration/Deceleration Curves, Button Control of the Motor, Loadable Speed Tables, Various lighting effects, decoder lock and many more.

**WARRANTY PROCEDURE:** All decoders are covered by a one year goof proof, no questions asked warranty. **Please return in a small box.** 

- 1. You MUST register the failed decoder on our website at <u>www.tcsdcc.com</u>. If you do not have access to a computer you MUST call to register your warranty at: (267) 733-3408
- 2. Print out a copy of the Warranty Registration and include it in the box with the decoder(s).
- 3. Return decoder(s) directly to us using the address below.

Compatible with NMRA DCC standards.

Made by TCS in the USA.

#### Train Control Systems P.O. Box 341 845 Blooming Glen Rd. Blooming Glen, PA 18911



Phone **215-453-9145** Fax **215-257-0735** Email **tcs@tcsdcc.com** Web **www.tcsdcc.com** 



### Our Famous GOOF PROOF NO Questions Asked Warranty




Scale	Functions	Function Rating	Continuous/Peak
НО	2	100 mA	1.0 /2.0 Amp

#### Dimensions: 0.474" x 0.702" x 0.16" or 12.04mm 17.83mm

This full featured, 2 function, Direct Plug decoder fits the Life Like FA1 as well as other Life Like locomotives with a headlight and a seperate mars light. Included is our auto-adjusting BEMF for outstanding slow speed performance and hassle free set up. Also includes Quiet Drive for super quiet engine performance.

Default Lighting Controls	Headlight	Mars Light		
Function Button Used	F0 (CV 33 = 1)	F1 (CV 34 = 4)		
Direction of Travel	Forward (CV 49 = 0)	Both Directions (CV 50 = 32)		

# WIRING DIAGRAM



List of Pin Connections:

4. & 5. Motor Connections
2. / 3. Mars Light
4. & 8. Rail Connections

## This Decoder Is RailCom equipped.

# INSTALLATION

For detailed installation pictures visit our website where we maintain a constantly growing database of a wide range of locomotives and decoders.



### **BASIC CONFIGURATION**

DADIC C	20111	100				
CV 29	Con	figu	ration			
A	0	1	Reverse the direction the engine runs.			
В	2	2	Use 28/128 speed step mode.			
C	4	4	Enable analog ( DC ) operation.			
D	0	16	Make the Loadable Speed Tables active.			
E	0	32	Make the decoder address 128 or higher.			
CV 29	6		Program the sum of the values you choose into CV 29			
	-					
2 Digit	1	dres				
CV 1	3		Record your choice here.			
4 Digit	t Ad	dres	S Make sure 4-digit Addressing is enabled in CV29			
CV 17	0		Record your four digit address here			
CV 17	0	-	Your command station will assign the values of CV 17 and CV1			
	0					
Consis	+ /	Idro	CC Add 129 to reverse the lass when in consist			
_		Jule				
CV 19	0		Use a 2 digit address when in a consist ( Multiple units ).			
Deser	امدا	م م ا				
Decod		OCK				
CV 15	0		All unlocked = 0Decoder to unlock = 1 - 6All locked = 1			
CV 16	1		Mobile = 1     Sound = 2     Light Only = 3     4     5     6			
To unlock a	a deco	der. m	nake CV 15 = 0 or CV 15 = CV 16. To lock a decoder, make CV 15 not equal to			
			e address decoders, make CV 15 = 7.			
Facto	ry R	<u>eset</u>				
CV 8	15	3 E	Enter 2 to perform a Factory Reset.			
			Rule 17 Dimming Options			
			D= BEMF OFF Odd number = BEMF ON			
BEMF disa			BEMF enabled = 1BEMF button control= 3Dims when stopped = 16			
			nd button control of it make CV 61 = 3 Opposite light dim = 32			
CV 61	1		BEMF and Dimming Control BEMF+Stopped + Opposite dim = 4			
CV 136		2	Function button control of BEMF     Bits 0-7 designates buttons 5-12			
CV 64			Dimmed Brightness (2 - 6 for LEDs, 12 - 18 for Bulbs)			
CV 10	0	)	BEMF Cut Out			
RailCo	m®					
		0	CV address pointer			
CV 178		0	CV address pointer			
CV 180		0	RailCom® Transmit Options			
CV 181		0	RailCom® Transmit Options			
CV 28		0	Broadcast enable			
			information on decoder features or programming visit:			
W	ww.to	<u>sdcc</u>	.com and check out the Complete Programming Guide.			
I						

### **MOTOR CONTROL**

Speed Graph									
CV 2	0		Start Volts Set the voltage when the throttle is first applied.						
CV 6	0		Mid Volts Set the voltage when the throttle is at midpoint.						
CV 5	0		Top Volts Set the voltage when the throttle is at full speed.						
Momentum									
CV 3	1		Acceleration Larger values add time to each speed step.						
CV 4	1		Deceleration Larger values add time to each speed step.						
CV 23	0		*Acceleration Adjustment when in Consist						
CV 24	0		*Deceleration Adjustment when in Consist						
*Values above 128 increase the adjustment * Values below 128 decrease the adjustment									
Motor Trim									
CV 66	0		Forward Trim	Values above 128 increase speed,					
CV 95	0		Reverse Trim	values below 128 decrease speed.					
Lighting Features				Light Effect	fwd	rev	both		
				Constant Bright Light	0	16	32		
	Light Function Wires		Random Flicker (fire box) 1	1	17	33			
CV 49	0		e Wire F0F	Mars Light	2	18	34		
CV 50	16	Yellov	w Wire FOR	Flashing Light	3	19	35		
				Single Pulse Strobe 1	4	20	36		
				Double Pulse Strobe 1	5	21	37		

Note: For more information on Quick Presets visit the Comprehensive Programming Guide at www.tcsdcc.com

#### Rule 17 Dimming Control

Rule 17 Dimming is turned on and off by button 4 as the default, but this value can be remapped via CV 123. See the Function Remapping guide on the literature section of www.tcsdcc.com for more info.

**Consist Lighting Control** 

**Lighting Quick Presets** 

0

10

11

12

CV 21

CV 8

CV 22 0

NTROL					
atures		fwd	rev	both	
aluies	Constant Bright Light		0	16	32
Wires	Randor	1	17	33	
White Wire F0F	Mars Light		2	18	34
Yellow Wire   FOR		3	19	35	
	Sing	4	20	36	
ng Control	Dou	5	21	37	
	Rotary Beacon		6	22	38
is turned on and off		7	23	39	
e default, but this	Rule 17 (dimmable light)		8	24	40
apped via CV 123. See	Ditch Light ( Left or Right )		10	26	42
apping guide on the of www.tcsdcc.com for	Ditch Light ( Other side )		11	27	43
of www.tcsdcc.com for	Constant Dim 1		12	28	44
	*Auto-Mars		13	29	45
	Brake Light(s)		14	30	46
	Single Pulse Strobe 2		15	31	47
	Double Pulse Strobe 2		64	80	96
	Random Flicker 2		65	81	97
	Constant Dim 2		66	82	98
ting Control	Constant Dim 3		67	83	99
ting Control	Constant Dim 4		68	84	100
Extra Functions		Green and Purple wire = 3			
Headlight Functions White and Yellow Wire = 3				3	
ick Presets					
Program a value of 10 to		5			ton 1
		ton two makes them		-	
		for default trolley se			
Program a value of 12	for stan	dard trolley settings	and ta	ail ligh	nts.