Main Features of this Decoder:

BEMF Load Compensation: Provides superior slow speed control performance under load.

Quiet Drive: Super-quiet motor control for "buzz" free motor performance.

DC Mode: Decoder will automatically detect DC power. You can also configure how your lighting effects function on DC.

<u>Variable Momentum:</u> Allows you to make custom acceleration and deceleration curves.

+12V Lighting: This decoder uses an unregulated 12V supply for lighting. For use with LED's, you must include current-limit resistors (1KΩ recommended).

<u>Function Remapping:</u> Buttons 0 through 12 may be used to control the lighting functions of this decoder.

<u>Programmable Lighting Effects:</u> Choose from 20 separate user-programmable lighting effects!

<u>Decoder Lock:</u> Feature which prevents accidental/unwanted programming

Speed Tables: Configure custom speed curves and set speed limits.

Other Features of This Decoder: This decoder has more features than could be listed in this pamphlet. For the complete list of available features, visit our website tcsdcc.com to download the "Comprehensive Programing Guide" found in the Documentation section of our website.

WARRANTY PROCEDURE: All decoders are covered by a one-year warranty. This decoder must be returned in a small box.

- 1. For registration, more details, and disclaimers, visit tcsdcc.com/warranty
- 2. Print out a copy of the Warranty Registration and include it in the box
- 3. Return decoder(s) directly to TCS using the address below.

Compatible with NMRA DCC standards

Designed & Built by TCS in the USA

Train Control Systems P.O. Box 341 845 Blooming Glen Rd. Blooming Glen, PA 18911



Phone 215-453-9145 Fax 215-257-0735 Email tcs@tcsdcc.com Web www.tcsdcc.com



Backed by our famous "GOOF-PROOF" Warranty




\	Scale	Functions	Function Rating	Continuous/Peal		
	N/HO	2	100 mA	1.0 /2.0 Amp		

Dimensions: 0.365" x 0.587" x 0.109" or 9.27mm 14.91mm 2.77mm

The M1 is a 2-function, hard-wire decoder small enough for N-Scale, but powerful enough for HO-scale. The M1 is designed for use in locomotives where a T-series is too large. This decoder may be hard-wired to your locomotive using the included wires.

WIRING DIAGRAM

Diagram drawn for clarity - wire decoder per the written wire colors. The wires on your decoder may not be lined up the same as the diagram.



INSTALLATION

For detailed installation examples visit our website where we maintain a constantly growing database of a wide range of locomotives and decoders.







BASIC CONFIGURATION

CV 29 Configuration					
Α	0	1	Reverse the direction the engine runs.		
В	2	2	Use 28/128 speed step mode.		
С	4	4	Enable analog (DC) operation.		
D	0	16	Make the Loadable Speed Tables active.		
Е	0	32	Make the decoder address 128 or higher.		
CV 29	6		Program the sum of the values you choose into CV 29		

2 Digit	Add	ress	Use if the address is 127 or less.
CV 1	3		Pocord your choice here

4 Digit Address			Make sure 4-digit Addressing is enabled in CV29
CV 17	0		Record your four digit address here
CV 18	0		Your command station will assign the values of CV 17 and CV18

Consist Address		dress	Add 128 to reverse the loco when in consist.	
CV 19	0		Use a 2 digit address when in a consist (Multiple units).	

Decoder Lock

CV 15	0	All unlocked	l = 0	De	ecoder to unlock	c = 1 - 6	All lo	cked = 7
CV 16	1	Mobile = 1	Sound	d = 2	Light Only = 3	4	5	6

To unlock a decoder, make CV 15 = 0 or CV 15 = CV 16. To lock a decoder, make CV 15 not equal to CV 16. To lock all same address decoders, make CV 15 = 7.

Factory Reset

CV 8 153 Program a value of 2 or 8 to perform a Factory Reset.

Back EMF and Rule 17 Dimming Options

Even number OR 0= BEMF OFF Odd number = BEMF ON

BEMF disabled = 0 BEMF enabled = 1		BEMF button control= 3 Dims when sto		Dims when stopped = 16	
Turn	on BEMF	and button control of		Opposite light dim = 32	
CV 61	1	BEMF and Dimming Control			NF+Stopped + Opposite dim = 49
CV 136	2	Function butto	n control of BEMF	Bits	0-7 designates buttons 5-12
CV 64	15	Dimmed Brigh	ntness	(2-6f	or LEDs, 12 - 18 for Bulbs)
CV 10	0	BEMF Cut Out			

RailCom® (If Supported)

	CV 178	0	CV address pointer
	CV 180	0	RailCom® Transmit Options
	CV 181	0	RailCom® Transmit Options
	CV 28	0	Broadcast enable

For more information on decoder features or programming visit: www.tcsdcc.com and check out the Complete Programming Guide.

MOTOR CONTROL

Speed Graph							
CV 2	0		Start Volts Set the	e voltage when the throttle is first applied.			
CV 6	0		Mid Volts Set the	voltage when the throttle is at midpoint.			
CV 5	0		Top Volts Set the	voltage when the throttle is at full speed.			
Momei	Momentum						
CV 3	1			er values add time to each speed step.			
CV 4	1			er values add time to each speed step.			
CV 23	0		*Acceleration Adjus	tment when in Consist			
CV 24	0		*Deceleration Adjus	stment when in Consist			
*Values ab	ove 1	28 incr	ease the adjustment	* Values below 128 decrease the adjustment			
Motor Trim							
CV 66	0		Forward Trim	Values above 128 increase speed,			
CV 95	0		Reverse Trim	values below 128 decrease speed.			

LIG

LIGHTING CONTROL							
Lighting Features					Light Effect	fwd	rev
Ligiting reatures			Constant Bright Light	0	16		
Light Function Wires				Random Flicker (fire box) 1	1	17	
CV 49	0	White Wire	F0F]	Mars Light	2	18
CV 50	16	Yellow Wire FOR			Flashing Light	3	19
				Single Pulse Strobe 1	4	20	
Rule 17 Dimming Control					Double Pulse Strobe 1	5	21
Rule 17 Dillilling Control				Dotami Passan	-	22	

Rule 17 Dimming is turned on and off by button 4 as the default, but this value can be remapped via CV 123. See the Function Remapping guide in the lighting section of docs.tcsdcc.com for more info.

Mars Light	2	18	34
Flashing Light	3	19	35
Single Pulse Strobe 1	4	20	36
Double Pulse Strobe 1	5	21	37
Rotary Beacon	6	22	38
Gyra Light	7	23	39
Rule 17 (dimmable light)	8	24	40
Ditch Light (Left or Right)	10	26	42
Ditch Light (Other side)	11	27	43
Constant Dim 1	12	28	44
*Auto-Mars	13	29	45
Brake Light(s)	14	30	46
Single Pulse Strobe 2	15	31	47
Double Pulse Strobe 2	64	80	96
Random Flicker 2	65	81	97
Constant Dim 2	66	82	98
Constant Dim 3	67	83	99
Constant Dim 4	68	84	100
			_

both 32

Consist Lighting Control

CV 21	0	Extra Functions	Green and Purple wire = 3
CV 22	0	Headlight Functions	White and Yellow Wire = 3

Lighting Quick Presets

	CV 8	10	Program a value of 10 to make violet and green ditch lights. Button 1 turns them on and Button two makes them blink.
		11	Program a value of 11 for default trolley settings.
		12	Program a value of 12 for standard trolley settings and tail lights.

Note: For more information on Quick Presets visit the Comprehensive Programming Guide at www.tcsdcc.com