Main Features of this Decoder:

BEMF Load Compensation: Provides superior slow speed control performance under load.

Quiet Drive: Super-quiet motor control for "buzz" free motor performance.

<u>DC Mode:</u> Decoder will automatically detect DC power. You can also configure how your lighting effects function on DC.

<u>Variable Momentum:</u> Allows you to make custom acceleration and deceleration curves.

LED-Ready Lighting: This decoder has on-board $1K\Omega$ resistors for use with LED's. It is not necessary to add your own external current-limiting resistors.

<u>Function Remapping:</u> Buttons 0 through 12 may be used to control the lighting functions of this decoder.

<u>Programmable Lighting Effects:</u> Choose from 20 separate user-programmable lighting effects!

<u>Decoder Lock:</u> Feature which prevents accidental/unwanted programming

Speed Tables: Configure custom speed curves and set speed limits.

Other Features of This Decoder: This decoder has more features than could be listed in this pamphlet. For the complete list of available features, visit our website tcsdcc.com to download the "Comprehensive Programing Guide" found in the Documentation section of our website.

WARRANTY PROCEDURE: All decoders are covered by a one-year warranty. This decoder must be returned in a small box.

- 1. For registration, more details, and disclaimers, visit tcsdcc.com/warranty
- 2. Print out a copy of the Warranty Registration and include it in the box
- 3. Return decoder(s) directly to TCS using the address below.

Compatible with NMRA DCC standards

Designed & Built by TCS in the USA

Train Control Systems P.O. Box 341 845 Blooming Glen Rd. Blooming Glen, PA 18911



Phone 215-453-9145 Fax 215-257-0735 Email tcs@tcsdcc.com Web www.tcsdcc.com



Backed by our famous "GOOF-PROOF" Warranty




\	Scale	Functions	Function Rating	Continuous/Peak	
/	НО	2	100 mA	1.3 /2.0 Amp	

Dimensions: 0.661" x 0.969" x 0.193" or 16.79mm 24.61mm 4.9mm

The T1 is a multi-purpose HO-scale decoder. This decoder may be hardwired or plugged directly into any locomotive with a 9-pin JST plug.

<u>Note:</u> The Green and Purple wires on this decoder are not used. The T1 is a 2-function decoder, but still uses the 9-pin JST which includes the Green and Purple wires.

WIRING DIAGRAM



INSTALLATION

For detailed installation examples visit our website where we maintain a constantly growing database of a wide range of locomotives and decoders.







BASIC CONFIGURATION

CV 29 Configuration					
Α	0	1	Reverse the direction the engine runs.		
В	2	2	Use 28/128 speed step mode.		
С	4	4	Enable analog (DC) operation.		
D	0	16	Make the Loadable Speed Tables active.		
Е	0	32	Make the decoder address 128 or higher.		
CV 29	6		Program the sum of the values you choose into CV 29		

2 Digit	Add	ress	Use if the address is 127 or less.
CV 1	3		Pocord your choice here

4 Digit Address			Make sure 4-digit Addressing is enabled in CV29		
CV 17	0		Record your four digit address here		
CV 18	0		Your command station will assign the values of CV 17 and CV18		

Consist Address		dress	Add 128 to reverse the loco when in consist.	
CV 19	0		Use a 2 digit address when in a consist (Multiple units).	

Decoder Lock

CV 15	0	All unlocked	l = 0	De	ecoder to unlock	c = 1 - 6	All lo	cked = 7
CV 16	1	Mobile = 1	Sound	d = 2	Light Only = 3	4	5	6

To unlock a decoder, make CV 15 = 0 or CV 15 = CV 16. To lock a decoder, make CV 15 not equal to CV 16. To lock all same address decoders, make CV 15 = 7.

Factory Reset

CV 8 153 Program a value of 2 or 8 to perform a Factory Reset.

Back EMF and Rule 17 Dimming Options

Even number OR 0= BEMF OFF Odd number = BEMF ON

BEMF disabled =0 BEMF enal		BEMF enabled = 1	BEMF button control= 3		Dims when stopped = 16	
Turn	on BEMF	and button control of		Opposite light dim = 32		
CV 61	1	BEMF and Dimming Control			NF+Stopped + Opposite dim = 49	
CV 136	2	Function butto	n control of BEMF	Bits	0-7 designates buttons 5-12	
CV 64	15	Dimmed Brigh	ntness	(2-6f	or LEDs, 12 - 18 for Bulbs)	
CV 10	0	BEMF Cut Out				

RailCom® (If Supported)

CV 178	0	CV address pointer
CV 180	0	RailCom® Transmit Options
CV 181	0	RailCom® Transmit Options
CV 28	0	Broadcast enable

For more information on decoder features or programming visit: www.tcsdcc.com and check out the Complete Programming Guide.

MOTOR CONTROL

Speed Graph							
CV 2	0		Start Volts Set the	e voltage when the throttle is first applied.			
CV 6	0		Mid Volts Set the	voltage when the throttle is at midpoint.			
CV 5	0		Top Volts Set the	voltage when the throttle is at full speed.			
Momei	Momentum						
CV 3	1			er values add time to each speed step.			
CV 4	1			er values add time to each speed step.			
CV 23	0		*Acceleration Adjus	tment when in Consist			
CV 24	0		*Deceleration Adjus	stment when in Consist			
*Values ab	ove 1	28 incr	ease the adjustment	* Values below 128 decrease the adjustment			
Motor Trim							
CV 66	0		Forward Trim	Values above 128 increase speed,			
CV 95	0		Reverse Trim	values below 128 decrease speed.			

LIG

LIGHTING CONTROL							
Lighting Features					Light Effect	fwd	rev
Ligiting reatures					Constant Bright Light	0	16
Light Function Wires				Random Flicker (fire box) 1	1	17	
CV 49	0	White Wire	F0F]	Mars Light	2	18
CV 50	16	16 Yellow Wire FOR			Flashing Light	3	19
					Single Pulse Strobe 1	4	20
Rule 17 Dimming Control				Double Pulse Strobe 1	5	21	
				Dotami Passan	-	22	

Rule 17 Dimming is turned on and off by button 4 as the default, but this value can be remapped via CV 123. See the Function Remapping guide in the lighting section of docs.tcsdcc.com for more info.

Mars Light	2	18	34
Flashing Light	3	19	35
Single Pulse Strobe 1	4	20	36
Double Pulse Strobe 1	5	21	37
Rotary Beacon	6	22	38
Gyra Light	7	23	39
Rule 17 (dimmable light)	8	24	40
Ditch Light (Left or Right)	10	26	42
Ditch Light (Other side)	11	27	43
Constant Dim 1	12	28	44
*Auto-Mars	13	29	45
Brake Light(s)	14	30	46
Single Pulse Strobe 2	15	31	47
Double Pulse Strobe 2	64	80	96
Random Flicker 2	65	81	97
Constant Dim 2	66	82	98
Constant Dim 3	67	83	99
Constant Dim 4	68	84	100
			_

both 32

Consist Lighting Control

CV 21	0	Extra Functions	Green and Purple wire = 3
CV 22	0	Headlight Functions	White and Yellow Wire = 3

Lighting Quick Presets

	CV 8	10	Program a value of 10 to make violet and green ditch lights. Button 1 turns them on and Button two makes them blink.
		11	Program a value of 11 for default trolley settings.
		12	Program a value of 12 for standard trolley settings and tail lights.

Note: For more information on Quick Presets visit the Comprehensive Programming Guide at www.tcsdcc.com