### Main Features of this Decoder

<u>Back EMF Load Compensation</u> for superior slow speed control even with heavy loads.

- Quiet Drive creates SUPER QUIET engine performance.
- <u>Autodetect</u> for realistic throttle response when using DC power.

### Non-Standard Default CV Values

CV	Value	Purpose
CV 51	16	Rear Light
CV 156	20	Headlight Power Setting
CV 52	37	Double Pulse Strobe (use a value of 36 for Single Pulse Strobe, or 38 for Rotary Beacon
CV 35	2	Function 1 remapped to button 0
CV 36	4	Function 2 remapped to button 1

Other Features of This Decoder: This decoder has too many features that could be listed on this page. For the complete list of available features, print out the "Additional Programing Guide" that can be found in the literature section of our website ( www.tcsdcc. com). Some of the features include: Function Remapping, 3 Point Acceleration/Deceleration Curves, Button Control of the Motor, Loadable Speed Tables, Various lighting effects, decoder lock and many more.

**WARRANTY PROCEDURE:** All decoders are covered by a one year goof proof, no questions asked warranty. **Please return in a small box.** 

- You MUST register the failed decoder on our website at <u>www.tcsdcc.com</u>. If you do not have access to a computer you MUST call to register your warranty at: (267) 733-3408
- 2. Print out a copy of the Warranty Registration and include it in the box with the decoder(s).
- 3. Return decoder(s) directly to us using the address below.

Compatible with NMRA DCC standards.

Made by TCS in the USA.

Train Control Systems P.O. Box 341 845 Blooming Glen Rd. Blooming Glen, PA 18911



Phone 215-453-9145
Fax 215-257-0735
Email tcs@tcsdcc.com
Web www.tcsdcc.com



# Our Famous GOOF PROOF NO Questions Asked Warranty



١	Scale	Functions	Function Rating	Continuous/Peak
4	N	6	80 mA	1.0 /2.0 Amp


Dimensions: 2.344"x0.49"x0.097" or 59.53mm x 12.46mm x 2.46mm

This full featured BEMF decoder is designed to fit the Kato N-Scale MP36PH Metra locomotive. Included is our auto-adjusting BEMF for outstanding slow speed performance. Also includes Quiet Drive for super quiet engine performance.

# WIRING DIAGRAM

This decoder features onboard 1K ohm 1/4 watt resistors for LED's on functions F3 and F4!

NOTE: Functions F1 and F2 do not include resistors for LED's



NOTE: For a functional rear light and strobe we produce the **K4-LK** lighting kit (sold seperately) which makes adding both lights a cinch.

# INSTALLATION

For detailed installation pictures visit our website where we maintain a constantly growing database of a wide range of locomotives and decoders.







### **BASIC CONFIGURATION**

CV 29	CV 29 Configuration				
Α	0	1	Reverse the direction the engine runs.		
В	2	2	Use 28/128 speed step mode.		
С	4	4	Enable analog ( DC ) operation.		
D	0	16	Make the Loadable Speed Tables active.		
Е	0	32	Make the decoder address 128 or higher.		
CV 29	6		Program the sum of the values you choose into CV 29		

2 Digit Address			Use if the address is 127 or less.
CV 1	3		Record your choice here.

4 Digit Address			Make sure 4-digit Addressing is enabled in CV29
CV 17	0		Record your four digit address here
CV 18	0		Your command station will assign the values of CV 17 and CV18

<b>Consist Address</b>		dress	Add 128 to reverse the loco when in consist.
CV 19	0		Use a 2 digit address when in a consist (Multiple units).

## **Decoder Lock**

CV 15	0	All unlocked	l = 0	De	ecoder to unlock	< = 1 - 6	All lo	cked = <b>7</b>
CV 16	1	Mobile = 1	Sour	nd = 2	Light Only = 3	4	5	6

To unlock a decoder, make CV 15 = 0 or CV 15 = CV 16. To lock a decoder, make CV 15 not equal to CV 16. To lock all same address decoders, make CV 15 = 7.

### **Factory Reset**

CV 8 153 Enter 2 to perform a Factory Reset.

# Back EMF and Rule 17 Dimming Options Even number OR 0= BEMF OFF Odd number = BEMF ON

BEMF disab	BEMF disabled =0   BEMF enabled = 1   BEMF button control=		ol= 3	Dims when stopped = 16	
Turn	on BEMF	and button control o		Opposite light dim = 32	
CV 61	1	BEMF and Dimr	ning Control	BEN	NF+Stopped + Opposite dim = 49
CV 136	2	Function butto	n control of BEMF	Bits	0-7 designates buttons 5-12
CV 64	15	Dimmed Brigh	ntness (	2 - 6 f	or LEDs, 12 - 18 for Bulbs )
CV 10	0	BEMF Cut Out			

### RailCom®

1100110011	Managani				
CV 178	0	CV address pointer			
CV 180	0	RailCom® Transmit Options			
CV 181	0	RailCom® Transmit Options			
CV 28	0	Broadcast enable			

For more information on decoder features or programming visit: www.tcsdcc.com and check out the Complete Programming Guide.

#### MOTOR CONTROL

Speed	Speed Graph					
CV 2	0		Start Volts Set the	e voltage when the throttle is first applied.		
CV 6	0		Mid Volts Set the	voltage when the throttle is at midpoint.		
CV 5	0		Top Volts Set the	voltage when the throttle is at full speed.		
Momei	Momentum					
CV 3	1		Acceleration Larger values add time to each speed step.			
CV 4	1		Deceleration Larg	ger values add time to each speed step.		
CV 23	0		*Acceleration Adjus	stment when in Consist		
CV 24	0		*Deceleration Adjus	stment when in Consist		
*Values ab	ove 1	28 incr	ease the adjustment	* Values below 128 decrease the adjustment		
Motor	Motor Trim					
CV 66	0		Forward Trim	Values above 128 increase speed,		
CV 95	0		Reverse Trim	values below 128 decrease speed.		

### LIGHTING CONTROL

# **Lighting Features**

Light Fu	nction	Wires
CV 40	0	\4/b:+

CV 49	0	White Wire	F0F
CV 50	16	Yellow Wire	F0R
CV 51	32	Green Wire	F1
CV 52	32	Violet Wire	F2
CV 53	32	Brown Wire	F3
CV 54	32	Pink Wire	F4

### **Rule 17 Dimming Control**

Rule 17 Dimming is turned on and off by button 4 as the default, but this value can be remapped via CV 123. See the Function Remapping guide on the literature section of www.tcsdcc.com for more info.

Constant Bright Light         0         16           Random Flicker (fire box) 1         1         17           Mars Light         2         18           Flashing Light         3         19	32 33 34 35 36 37
Mars Light         2         18           Flashing Light         3         19	34 35 36
Flashing Light 3 19	35 36
3 3 1	36
Charle D. Lee Charles 4 20	_
Single Pulse Strobe 1 4 20	27
Double Pulse Strobe 1 5 21	37
Rotary Beacon 6 22	38
Gyra Light 7 23	39
Rule 17 (dimmable light) 8 24	40
Ditch Light ( Left or Right ) 10 26	42
Ditch Light (Other side ) 11 27	43
Constant Dim 1 12 28	44
*Auto-Mars 13 29	45
Brake Light(s) 14 30	46
Single Pulse Strobe 2 15 31	47
Double Pulse Strobe 2 64 80	96
Random Flicker 2 65 81	97
Constant Dim 2 66 82	98
Constant Dim 3 67 83	99
Constant Dim 4 68 84	100

# **Consist Lighting Control**

CV 21 0	Extra Functions	Green and Purple wire = 3
CV 22 0	Headlight Functions	White and Yellow Wire = 3

### **Lighting Quick Presets**

CV 8	10	Program a value of 10 to make violet and green ditch lights. Button 1 turns them on and Button two makes them blink.
	11	Program a value of 11 for default trolley settings.
	12	Program a value of 12 for standard trolley settings and tail lights.
Note: For more information on Quick Presets visit the Comprehensive Programming Guide at www.tcsdcc.com		