Main Features of this Decoder

- <u>Back EMF Load Compensation</u> for superior slow speed control even with heavy loads.
- **<u>Quiet Drive</u>** creates SUPER QUIET engine performance.
- <u>Autodetect</u> for realistic throttle response when using DC power.
- Dimmed Brightness of bulbs or LEDs is adjustable.
- Variable Momentum lets you make custom acceleration curves.
- **<u>Ditch Lights:</u>** control alternating ditch lights with realistic pulsing.
- Mars, Gyra, and Rotary Beacon are adjustable.
- <u>Decoder Lock</u> for programming same address decoders independently.
- **<u>Function Remapping:</u>** 13 buttons for most lights, 7 buttons for operations.
- **Other Features of This Decoder:** This decoder has too many features that could be listed on this page. For the complete list of available features, print out the "Additional Programing Guide" that can be found in the literature section of our website (www.tcsdcc. com). Some of the features include: Function Remapping, 3 Point Acceleration/Deceleration Curves, Button Control of the Motor, Loadable Speed Tables, Various lighting effects, decoder lock and many more.

WARRANTY PROCEDURE: All decoders are covered by a one year goof proof, no questions asked warranty. **Please return in a small box.**

- 1. You MUST register the failed decoder on our website at <u>www.tcsdcc.com</u>. If you do not have access to a computer you MUST call to register your warranty at: (267) 733-3408
- 2. Print out a copy of the Warranty Registration and include it in the box with the decoder(s).
- 3. Return decoder(s) directly to us using the address below.

Compatible with NMRA DCC standards.

Made by TCS in the USA.

Train Control Systems P.O. Box 341 845 Blooming Glen Rd. Blooming Glen, PA 18911



Phone **215-453-9145** Fax **215-257-0735** Email **tcs@tcsdcc.com** Web **www.tcsdcc.com**



Our Famous GOOF PROOF NO Questions Asked Warranty




١	Scale	Functions	Function Rating	Continuous/Peak
	N	4	80 mA	1.0 /2.0 Amp

Dimensions: 2.35"x0.413"x0.072" or 59.77mm x 10.49mm x 1.81mm

This full featured BEMF decoder is designed to fit the Kato N-Scale FEF Locomotive. This decoder includes an onboard LED for the front headlight and 3 solder pads for additional lights. Included is our auto-adjusting BEMF for outstanding slow speed performance and hassle free set up. Also includes Quiet Drive for super quiet engine performance.





INSTALLATION

For detailed installation pictures visit our website where we maintain a constantly growing database of a wide range of locomotives and decoders.





BASIC CONFIGURATION

CV 29	Con	figu	rat	tion			
Α	0	1		Reverse the direction the engine runs.			
В	2	2		Use 28/128 speed step mode.			
С	4	4	1	Enable analog ([
D	0	16	1	Make the Loadable Sp			
E	0	32	1	Make the decoder add			
CV 29	6					es you choose into CV 29	
2 Digit	۸d	droc	c	Use if the address	ic 17	27 or loss	
CV 1	3		<u> </u>	Record your choice here		27 01 (633.	
				the core your endice her			
4 Digit	Ad	dres	S	Make sure 4-digit Address	ing i	is enabled in CV29	
CV 17	0			Record your four digit a			
CV 18	0			Your command station will assig	gn th	e values of CV 17 and CV18	
Consis	<u>st Ac</u>	<u>ldre</u>	SS	Add 128 to reverse the	loco	o when in consist.	
CV 19	0			Use a 2 digit address when in	n a c	onsist (Multiple units).	
Decod	or I	ock					
		.OCK	1		11-		
CV 15	0	_		unlocked = 0 Decoder to un		I	
CV 16	1			bile = 1 Sound = 2 Light Only CV 15 = 0 or CV 15 = CV 16. To lock a		4 5 6	
CV 16. To lock all same address decoders, make CV 15 = 7. Factory Reset							
CV 8	15	3 E	Ente	r 2 to perform a Factory Reset.			
	mber	OR)= B	LIE 17 Dimming Options EMF OFF Odd number = BEMF F enabled = 1 BEMF button control	ON	Dims when stopped = 16	
				utton control of it make CV 61 = 3		Opposite light dim = 32	
CV 61	1			BEMF and Dimming Control	BEM	AF+Stopped + Opposite dim = 4	
CV 136	1	2		Function button control of BEMF Bits 0-7 designates buttons 5-12			
CV 64		5				for LEDs, 12 - 18 for Bulbs)	
CV 10	()		BEMF Cut Out			
CV 178 CV 180 CV 181	CV 180 0 RailCom® Transmit Options						
CV 28		0		Broadcast enable			
				rmation on decoder features <u>m</u> and check out the Complet			

MOTOR CONTROL

Speed	Speed Graph					
CV 2	0		Start Volts Set the	Start Volts Set the voltage when the throttle is first applied.		
CV 6	0			voltage when the throttle is at midpoint.		
CV 5	0		Top Volts Set the	voltage when the throttle is at full speed.		
Mome	Momentum					
CV 3	1		Acceleration Larger values add time to each speed step.			
CV 4	1		Deceleration Larger values add time to each speed step.			
CV 23	0		*Acceleration Adjustment when in Consist			
CV 24	0		*Deceleration Adjustment when in Consist			
*Values ab	*Values above 128 increase the adjustment * Values below 128 decrease the adjustmen					
Motor	Motor Trim					
CV 66	0		Forward Trim	Values above 128 increase speed,		
CV 95	0		Reverse Trim	values below 128 decrease speed.		

LIGHTING CONTROL

Lighting Features

Light Function Wires					
CV 49	0	White Wire	F0F		
CV 50	16	Yellow Wire	FOR		
CV 51	32	Green Wire	F1		
CV 52	32	Violet Wire	F2		

Rule 17 Dimming Control

Rule 17 Dimming is turned on and off by button 4 as the default, but this value can be remapped via CV 123. See the Function Remapping guide on the literature section of www.tcsdcc.com for more info.

Light Effect	fwd	rev	both
Constant Bright Light	0	16	32
Random Flicker (fire box) 1	1	17	33
Mars Light	2	18	34
Flashing Light	3	19	35
Single Pulse Strobe 1	4	20	36
Double Pulse Strobe 1	5	21	37
Rotary Beacon	6	22	38
Gyra Light	7	23	39
Rule 17 (dimmable light)	8	24	40
Ditch Light (Left or Right)	10	26	42
Ditch Light (Other side)	11	27	43
Constant Dim 1	12	28	44
*Auto-Mars	13	29	45
Brake Light(s)	14	30	46
Single Pulse Strobe 2	15	31	47
Double Pulse Strobe 2	64	80	96
Random Flicker 2	65	81	97
Constant Dim 2	66	82	98
Constant Dim 3	67	83	99
Constant Dim 4	68	84	100

Consist Lighting Control

CV 21	0	Extra Functions	Green and Purple wire = 3			
CV 22	0	Headlight Functions White and Yellow Wire =				
Lighting Quick Presets						
CV 8	10	Program a value of 10 to make violet and green ditch lights. Button 1 turns them on and Button two makes them blink.				
	11	Program a value of 11 for default trolley settings.				
	12 Program a value of 12 for standard trolley settings and tail lights.					
Note: For more information on Quick Presets visit the Comprehensive Programming Guide at www.tcsdcc.com						